

DUROSTICK SPACERS



For even grout joints



PROPERTIES

DUROSTICK SPACERS maintain equal width grout joints between tiles, throughout any installation shape, size and project. The cross shape (+), is available in a variety of sizes (1,2,3,4,5,7,9 and 10mm). The tee shape (T) is available in a variety of sizes also. There are also the wye shape (Y), available, and the wedge, thus making certain the available spacers can cover the most elaborate, intricate applications. Their special features include their smoothness and their resiliency, making them easy to clean with water and reusable when removed in time.

APPLICATIONS

Mainly used for ceramic tile installations, but also for decorative and natural stone installations, as well as marble and granite.

USE

DUROSTICK SPACERS can be used before or after the tile touches the adhesive. It is essential to fit the spacers to the tiles perfectly, avoiding uneven grout joints. When using DUROSTICK

adhesive, the spacers can be removed from wall applications after 3 hours from completion, and 2 hours after floor application completion.

CONSUMPTION

On the following table, find examples with the usual tile-spacer combinations, and their consumption:

TILE DIMENSIONS	SPACER	CONSUMPTION
15 x 20 cm	3 mm	48 τεμ. / m ²
20 x 20 cm	2 mm	36 τεμ. / m ²
30 x 30 cm	3 mm	19 τεμ. / m ²
40 x 40 cm	5 mm	15 τεμ. / m ²

DUROSTICK SPACERS



For even grout joints

PACKAGING

500 pcs. CROSSES 2,3,4,5,7,9mm

250 pcs. CROSSES 10mm

1000 pcs. CROSSES 1mm

500 pcs. WEDGE

500 pcs. TEE (T) 2,3,4,5,7,9mm

500 pcs. WYE (Y) 3mm

DUROSTICK A.B.E.E.

ΒΙΟΜΗΧΑΝΙΑ ΣΥΓΚΟΛΛΗΤΙΚΩΝ ΥΛΩΝ, ΧΡΩΜΑΤΩΝ &
ΚΟΝΙΑΜΑΤΩΝ

ΑΘΗΝΑ: ΑΣΠΡΟΠΥΡΓΟΣ ΑΤΤΙΚΗΣ, ΤΚ 193 00,

Τηλ.: 211 60 03 500-599, 210 55 16 500, 210 55 98 350,

Φαξ: 210 55 99 612

ΘΕΣΣΑΛΟΝΙΚΗ: ΒΙ.ΠΕ. Θ. - ΣΙΝΔΟΣ, Ο.Τ. 44, ΟΔΟΣ ΔΑ

10, ΤΚ 570 22, Τηλ.: 2310 795 797, 2310 797 365, Φαξ:

2310 797 367

Email: info@durostick.gr